


e. Beckmann


www.beckmann-cashagen.de

Spielgeräte Zubehör – playground equipment accessories


Tischtennisplatte / Ping Pong Table




Montageanleitung / Assembly Instructions




nr/no.	Teileliste	Anz. / pcs.	List of parts
1	Obere Platte	2	Top plate
2	Stützfuß	4	Leg
3	Verbinder	1	Connector
4	Stahlnetz	1	Steel net
5	Flansch	2	Plate
6	Anker	4	Anchor
A	Schraube M8x25	24	Screw M8x25
B	Inbusschraube M8x60	8	Allen screw M8x60
C	Schraube M8x30	4	Screw M8x30
D	Schraube M8x55	4	Screw M8x55
B/D	Mutter M8	12	Nut M8
A/B/C/D	Federscheibe	40	Spring washer
E	Inbusschlüssel	1	Allen key
A/B/C/D	Unterlegscheibe	40	Washer




Rys. 1 / Pic 1




Rys. 2 / Pic 2




Rys. 3 / Pic 3




Rys. 4 / Pic 4



Rys 5 / Pic 5



Rys 6 / Pic 6



Rys 7 / Pic 7

